



OLYMPIA
EXPRESS

Instructions for descaling: Cremina.

Descale your machine regularly, depending on the hardness of your water 1 to 2 times per year. Only use a commercially available liquid decalcifying solution in accordance with the manufacturer's instructions.

Please do not use acetic acid nor white vinegar!

Instructions Cremina

- 01** Open the boiler top of your Cremina. Empty the boiler water. Pour in the liquid descaling agent into the boiler and fill it with water.
- 02** Open the steam tab of your Cremina and close the boiler top. Leave the cold liquid to work for 2 to 3 hours.
- 03** Place a container under the steam tab and another container under the brew group of your Cremina.
- 04** Empty out the descaling liquid and rinse the boiler 2 to 3 times with fresh water. Fill the Cremina with fresh water, only now heat up the machine.
- 05** Let the steam come through the steam valve and perform 2 to 3 extractions without portafilter with your Cremina.

For very hard tap water we suggest using lime-free water or a filter.

Note: These instructions replace all previous descaling instructions in the owner's book and online.

Swiss manufacturer of
finest espresso machines.

Olympia Express SA
Burgstrasse 26
8750 Glarus
Switzerland

T +41.91.646 15 55
F +41.91.646 15 69

info@olympia-express.ch
www.olympia-express.ch